

## **Instructions for Replacing a Hand Control**

Removing the existing hand control:

- Pull the cord firmly away from the control box until it is unplugged.

Installing the new hand control:

- Plug the new hand control into the same port as the old hand control.
- Ensure the hand control is fully plugged in-you should hear a click into place.
- \*A green light should appear in the top right corner confirming the hand control is plugged in and ready to use.

\*All of the hand controls are tested for quality control before they leave our facility. If the hand control is not working after it is plugged into the control box make sure it is completely plugged. Afterwards, if the hand control is still not working please contact us immediately as the problem could actually be with the control box. We will assist you further on this matter, should that be the case.